FROM THE TIME IT RAINS...


C O N T R O L

...TO THE TIME IT DRAINS

Hydro-Channel's interior basement floor waterproofing system along with a 4 inch clean rock subgrade will eliminate any possibility of hydrostatic pressure occuring, which will force water up through the basement floor. Hydro-Channel is proven to be 100% effective when installed according to manufacturer's instructions.



The Hydro-Channel installed overlapping onto a 4 inch clean rock subgrade which will allow the system to drain into perforated sump container.



Full basement (a basement below ground level)

- * If a good clean 4 inch rock subgrade can not be provided, then a footing drain should be installed below floor level to help keep the water level below the bottom of the floor.
- * If there is no sump container installed, a gravity drain or daylight drain must be in place to drain the 4 inch rock subgrade.